



INSTALLATION DETAIL

INSTALLATION:

1. DETERMINE WHERE PANELS ARE TO BE PLACED.
2. CLEAN WALL AREAS WHERE ADHESIVE BACKING WILL CONTACT.
3. JOIN HOOK AND LOOP VELCRO ON PANEL BACK. REMOVE BACKING FROM WALL-MOUNTED VELCRO. LOCATE AND PRESS PANEL FIRMLY ON WALL (ALLOW ADHESIVE TO CURE BEFORE TRYING TO REMOVE PANEL FROM WALL)
4. KNC DOES NOT RECOMMEND THIS MOUNTING METHOD WHEN WALL SURFACE IS BLOCK, BRICK, OR CONCRETE.
5. WHEN USING VELCRO, PANELS SHOULD BE SUPPORTED BY USE OF BOTTOM SUPPORT ANGLE, MOLDING, OR SOME MEANS OF CARRYING FULL WEIGHT OF PANEL.

NOTES:

1. STRIPS TO BE PLACED ON FABRIC RETURN
2. HOOK AND LOOP PROVIDED BY KNC
3. WHEN PANEL IS COMPLETELY SUSPENDED ABOVE FLOOR KNC RECOMMENDS THE USE OF CONTINUOUS VELCRO COVERAGE
4. TYP. VELCRO STRIPS TO BE 6" LONG