



INSTALLATION INSTRUCTIONS APPLIQUE ACOUSTICAL WALL PANEL

KINETICS ACOUSTICAL WALL PANELS ARE EASILY WALL-MOUNTED USING CONCEALED MOUNTING BRACKETS. PANELS CAN BE INSTALLED QUICKLY ONTO VIRTUALLY ANY WALL SURFACE. FOR A LEVEL, SECURE INSTALLATION FOLLOW THESE GUIDELINES:

1. BEFORE INSTALLATION, CHECK WALLS FOR OBSTRUCTIONS SUCH AS ELECTRICAL OUTLETS, THERMOSTATS AND SWITCHES. PANELS SHOULD BE MOUNTED TO AVOID THESE, IF POSSIBLE.
2. INSTALL TOP MOUNTING BRACKET
MEASURE 2 1/4" DOWN FROM DESIRED TOP OF PANEL (IF PANELS BUTT INTO CEILING MAKE SURE TO ALLOW AN ADDITIONAL 3/4" AT TOP OF PANEL FOR ROOM TO SLIDE PANEL ONTO TOP BRACKET). DO NOT POSITION WALL CLIPS CLOSER THAN 3" FROM LEFT OR RIGHT VERTICAL EDGE OF PANEL. FASTEN CLIPS TO WALL.
3. INSTALL BOTTOM MOUNTING BRACKET
HANG PANEL FROM TOP CLIPS AT DESIRED FINAL LOCATION. MAKE SMALL MARK ON WALL UNDER BOTTOM EDGE AND REMOVE PANEL. FASTEN BOTTOM MOUNTING BRACKET TO WALL MAKING SURE ONE LEG OF ANGLE WILL BE BEHIND PANEL WHEN REHUNG.
4. HANG PANEL
SLIDE PANEL DOWN ONTO TOP BRACKETS. DRIVE SCREWS THRU FABRIC-COVERED FLANGE OF BOTTOM BRACKET INTO PANEL FRAME TO LOCK PANEL INTO POSITION.