

NOTE:

1. PAD MADE FROM NDM FLEXCO MATERIAL.
2. PAD DESIGNED TO BE USED UNDER FLSS BASE PLATE.

FLSS BASE PLATE FLEXCO SPACER PAD						
METRIC (mm AND kg)						
ITEM	SPACER DIMENSION				USE SPACER WITH THIS ISOLATOR	WHEN PAIRED WITH THIS ISOLATOR
	A	B	C	D		
01	229	102	16	17	FLSS-1-50/3500	FLSS-1-2500/7000
03	387	127	16	17	FLSS-1-2500/7000	FLSS-1-5000/14000
05	254	127	51	17	FLSS-2-100/1975	FLSS-2-2000/4500
07	445	152	22	17	FLSS-2-4000/9000	FLSS-2-8000/18000
09	279	152	51	17	FLSS-4-100/1600	FLSS-4-2250/5800
11	413	203	6	17	FLSS-4-2250/5800	FLSS-4-5500/11600

